



POWER  
SOLUTIONS


# PROTECT 1 LCD

User Manual

Protect 1 LCD 10 kVA

Protect 1 LCD 15 kVA

Protect 1 LCD 20 kVA



Thank you for purchasing the AEG UPS PROTECT 1 LCD from AEG Power Solutions. Safety information and operating instructions are included in this manual. To ensure correct use of the UPS, please read this manual thoroughly before operating it. Use this manual properly.

# CONTENT

|     |  |    |
|-----|--|----|
| 1   | Introduction.....  | 11 |
| 1.1 | Product features.....                                      | 11 |
| 1.2 | Environmental protection.....                              | 12 |
| 2   | Product Overview.....                                      | 13 |
| 2.1 | Model list.....  | 13 |
| 2.2 | Presentation.....  | 14 |
| 3   | Product Overview.....                                      | 18 |
| 3.1 | Unpacking and inspecting.....                              | 18 |
| 3.2 | Checking the accessory kit.....                            | 19 |
| 3.3 | Mechanical installation.....                               | 19 |
| 3.4 | Power cables connection.....                               | 21 |
| 3.5 | Gland kit installation.....                                | 33 |
| 4.  | Parallel System Installation and Operation (Optional)..... | 34 |
| 4.1 | Wiring for AC/DC cable.....                                | 34 |
| 4.2 | Wiring for parallel signal cable.....                      | 41 |
| 4.3 | Parallel system operation.....                             | 42 |
| 5.  | Operation.....   | 43 |
| 5.1 | LCD panel.....   | 43 |
| 5.2 | LCD description.....                                       | 44 |
| 5.3 | Menu structure.....  | 46 |
| 5.4 | Control and product information.....                       | 47 |
| 5.5 | User settings.....   | 47 |
| 5.6 | Starting the UPS with utility.....                         | 49 |
| 5.7 | Starting the UPS on battery.....                           | 50 |
| 5.8 | UPS shutdown.....  | 51 |
| 6   | Communication.....   | 52 |
| 6.1 | RS232 and USB.....   | 52 |
| 6.2 | UPS remote control functions.....                          | 52 |
| 7   | UPS Maintenance.....                                       | 54 |
| 7.1 | Equipment care.....  | 54 |
| 7.2 | Transporting the UPS.....                                  | 54 |
| 7.3 | Storing the equipment.....                                 | 54 |

|     |                                 |    |
|-----|---------------------------------|----|
| 7.4 | Recycle.....                    | 54 |
| 8   | Troubleshooting .....           | 56 |
| 8.1 | Typical alarms and faults ..... | 56 |
| 9   | Troubleshooting .....           | 60 |
| 9.1 | UPS block diagram .....         | 60 |
| 9.2 | UPS specification .....         | 60 |

### Revision

|    | Change  | Date       | Name |
|----|---------|------------|------|
| 00 | Created | 21.07.2021 | AN   |
|    |         |            |      |
|    |         |            |      |
|    |         |            |      |
|    |         |            |      |



# SAFETY INSTRUCTIONS

**SAVE THESE INSTRUCTIONS.** This manual contains important instructions that should be followed during installation and maintenance of the UPS and batteries.

The UPS that are covered in this manual are intended for installation in an environment within 0 to 40°C, free of conductive contaminant.

## Special symbols



**RISK OF ELECTRIC SHOCK** - Observe the warning associated with the risk of electric shock symbol.



Important instructions that must always be followed.



**Pb**


EU separate collection and lead content mark for lead acid batteries. Indicates that the battery must not be disposed of to the normal household waste but be separately collected and recycled.



EU separate collection mark for waste electrical and electronic equipment (WEEE). Indicates that the item must not be disposed of to the normal household waste but be separately collected and recycled.



Information, advice, help.



Refer to the user manual.

# Safety of persons

- RISK OF VOLTAGE BACKFEED. The system has its own power source (the battery). Isolate the UPS and check for hazardous voltage upstream and downstream during lockout-tagout operation. Terminal blocks may be energized even if the system is disconnected from the AC power source.
- Dangerous voltage levels are present within the system. It should be opened exclusively by qualified service personnel.
- The system must be properly grounded.
- The battery supplied with the system contains small amounts of toxic materials. To avoid accidents, the directives listed below must be observed:
  - Servicing of batteries should be performed or supervised by personnel knowledgeable about batteries and the required precautions.
  - When replacing batteries, replace with the same type and number of batteries or battery packs.
  - Do not dispose of batteries in a fire. The batteries may explode.
  - Batteries constitute a danger (electrical shock, burns). The short-circuit current may be very high.
- Precautions must be taken for all handling:
  - Wear rubber gloves and boots.
  - Do not lay tools or metal parts on top of batteries.
  - Disconnect charging source prior to connecting or disconnecting battery terminals.
  - Determine if battery is inadvertently grounded. If inadvertently grounded, remove source from ground. Contact with any part of a grounded battery can result in electrical shock. The likelihood of such shock can be reduced if such grounds are removed during installation and maintenance (applicable to equipment and remote battery supplies not having a grounded supply circuit).



# Product safety

- The UPS connection instructions and operation described in the manual must be followed in the indicated order.
- UPS enclosure IP rating IP20.
- CAUTION - To reduce the risk of fire, the unit connects only to a circuit provided with branch circuit overcurrent protection.
- The upstream circuit breaker for Normal AC/Bypass AC must be easily accessible. The unit can be disconnected from AC power source by opening this circuit breaker.
- An additional AC contactor is used for back feed protection and must comply with IEC/EN 62040-1 (the creep age and clearance distances shall meet the basic insulation requirements for pollution degree 2).
- Disconnection and overcurrent protection devices shall be provided by others for permanently connected AC input (Normal AC/Bypass AC) and AC output circuits.
- Check that the indications on the rating plate correspond to your AC powered system and to the actual electrical consumption of all the equipment to be connected to the system.
- For PLUGGABLE EQUIPMENT, the socket-outlet shall be installed near the equipment and shall be easily accessible.
- Never install the system near liquids or in an excessively damp environment.
- Never let a foreign body penetrate inside the system.
- Never block the ventilation grates of the system.
- Never expose the system to direct sunlight or source of heat.
- If the system must be stored prior to installation, storage must be in a dry place.
- The admissible storage temperature range is -25°C to +55°C without battery (-15°C to +40°C with battery).
- TN-S/IT/TN-C/TT of electrical supply system may be connected by UPS.
- This UPS may be provided with a maximum of 6 extension battery cabinets or equivalent.

# Special precautions

- The unit is heavy: wear safety shoes and use vacuum lifter preferentially for handling operations.
- All handling operations will require at least two people (unpacking, lifting, installation in rack system).
- Before and after the installation, if the UPS remains de-energized for a long period, the UPS must be energized for a period of 24 hours, at least once every 6 months (for a normal storage temperature less than 25°C). This charges the battery, thus avoiding possible irreversible damage.
- During the replacement of the Battery Module, it is imperative to use the same type and number of elements as the original Battery Module provided with the UPS to maintain an identical level of performance and safety.
- This is a category C3 UPS product. In a residential environment, this product may cause radio interference, in which case the user may be required to take additional measures.

# 1 Introduction

Thank you for selecting our UPS to protect your electrical equipment.

We recommend that you take the time to read this manual to take full advantage of the many features of your UPS.

Before installing your UPS, please read the booklet presenting the safety instructions. Then follow the indications in this manual.

## **EBM stands for External Battery Modules**

## 1.1 Product features

The UPS protects your sensitive electronic equipment from the most common power problems, including power failures, power sags, power surges, brownouts, line noise, high voltage spikes, frequency variations, switching transients, and harmonic distortion.

### **Technical data:**

- Double conversion with pure sine waveform output
- VFI SS 111 @230V/50Hz according to IEC/EN 62040-3
- Full digital control
- Output PF up to 1
- High charger capability, the charger current is up to 13 A
- Smart charging method to expand battery lifetime
- Auto detection of EBM's connected to the UPS
- Communication ports: RPO, Dry contacts (input and output), intelligent slot (for SNMP card), USB (for Service and Customer use), RS232 (for Service and Customer use)
- Dot-matrix touch-screen LCD, supporting multi-language
- Phases configurations: 3/3 (default); 3/1; 1/1.
- ECO Mode
- Start-able without battery
- "CVCF" mode (Frequency Converter Mode)

## 1.2 Environmental protection

Products are developed according to an eco-design approach.

### **Substances**

This product does not contain CFCs, HCFCs or asbestos.

### **Packing**

To improve waste treatment and facilitate recycling, separate the various packing components.

- The cardboard we use comprises over 50% of recycled cardboard.
- Sacks and bags are made of polyethylene.
- Packing materials are recyclable.

Follow all local regulations for the disposal of packing materials.

### **Product**

The product is mainly made up of recyclable materials.

Dismantling and disassembly must take place in compliance with all local regulations concerning waste. At the end of its service life, the product must be transported to recycling centers, re-use and treatment facilities for waste electrical and electronic equipment (WEEE).

### **Battery**

The product contains lead-acid batteries that must be processed according to applicable local regulations concerning batteries.

The battery may be removed to comply with regulations and in view of correct disposal.

# 2 Product Overview

## 2.1 Model list



The weight in this table is reference only, please see the labels on the carton for details.

| Product | Description           | Net Weights (kg) | Unit Size (W x H x D) (mm) |
|---------|-----------------------|------------------|----------------------------|
| UPS     | 10kVA with batteries  | 107.4            | 300*805*727                |
|         | 10kVA w/o batteries   | 55.4             |                            |
|         | 15kVA with batteries  | 161.6            |                            |
|         | 15kVA w/o batteries   | 59.1             |                            |
|         | 20kVA with batteries  | 161.6            |                            |
|         | 20kVA w/o batteries   | 59.1             |                            |
| EBM     | BP for 10kVA          | 115.6            | 225*589*518                |
|         | Empty BP for 10kVA    | 13               |                            |
|         | BP for 15/20kVA       | 115.6            |                            |
|         | Empty BP for 15/20kVA | 13               |                            |

Optional modular or accessory:

If order other type function modular or accessories, please contact distributors/agents.


| Type             | Description                                       | Remark                            |
|------------------|---|-----------------------------------|
| Intelligent Card | Dry Contact card (AS400)                          | See in chapter 6.5                |
|                  | NMC card  |                                   |
|                  | MODBUS card (CMC)                                 |                                   |
| EMP              | Temperature and humidity sensors                  |                                   |
| WLAN module      | WLAN module                                       | Wireless connection for IoT       |
| Battery cable    | Battery cable for UPS connect with user's own EBM | 1.8m length, see in chapter 3.4.3 |

## 2.2 Presentation

### 2.2.1 UPS model:


#### Front view

1. Ventilation area
2. LCD Modular, including:
  - (1)---Power button
  - (2)---Touch screen
  - (3)---LED indicator




## Rear view

1. Intelligent slot
2. RS232
3. Ethernet port (RJ45, for IoT function)
4. USB
5. Disabled
6. Parallel port
7. Dry contacts (input/output)
8. RPO (Remote Power Off) contact
9. RJ45 (for EBM detect)
10. Maintenance bypass switch
11. Main input switch and bypass input switch
12. AC Input /Output terminals
13. External battery port



## EBM (External Battery Module) - Front view


1. Ventilation area
2. EBM label





### EBM (External Battery Module) - Rear view

1. Fuse board cover (replace EBM fuse)
2. EBM port 1
3. EBM port 2
4. EBM detection (RJ45 port)



# 3 Product Overview

It is recommended to move the equipment to the installation site by using a pallet jack or a truck before unpacking.

The system may be installed only by qualified electricians in accordance with applicable safety regulations.

The cabinet is heavy, please install it with at least two peoples.


## 3.1 Unpacking and inspecting




Unpacking the unit in a low-temperature environment may cause condensation occurred in and on the cabinet. Do not install the unit until the inside and outside of the unit are absolutely dry (hazard of electric shock).

If any equipment has been damaged during shipment, keep the shipping cartons and packing materials for the carrier or place of purchase and file a claim for shipping damage. If you discover damage after acceptance, file a claim for concealed damage.

UPS



EBM



**Note:**

The cabinet is heavy, please see weight provided on the carton/label.

Do not lift the unit's front panel and rear panel.

Discard or recycle the packaging in a responsible manner or store it for future use.



Packing materials must be disposed in compliance with all local regulations concerning waste.

## 3.2 Checking the accessory kit

Verify that the following additional items are included with the unit.

|                     | Standard model  | EBM                                |
|---------------------|-----------------|------------------------------------|
|                     | UPS 10K/15K/20K |                                    |
| Battery cable       |                 | ✓<br>(two for every EBM delivered) |
| EBM detection cable |                 | ✓<br>(one for every EBM delivered) |
| Copper busbar       | ✓               |                                    |
| Gland kit           | ✓               |                                    |
| USB cable           | ✓               |                                    |
| RS232 cable         | ✓               |                                    |
| Parallel cable      | ✓               |                                    |
| Tower foot          | ✓               | ✓                                  |
| Quick start (EBM)   |                 | ✓                                  |
| User manual (UPS)   | ✓               |                                    |


Note: ✓ --- Standard configuration;

## 3.3 Mechanical installation

To keep air-flowing freely, it is recommended to keep a clearance with 500 mm space both for front and rear side.

### UPS model

1. Place the unit on a flat surface in its final location and install 'Tower foot' for stability.
2. Install the unit to ground(optional): place 4pcs bolts (M8 is recommended) to the final location previously, bolt's position please refer to below, then fix the unit to the bolts.




### EBM model



It is recommended to place EBM module(s) on the right side of the UPS.

1. Place the unit on a flat surface in its final location and install 'Tower foot' for stability.
2. Install the unit to ground (optional): place 4pcs bolts (M8 is recommended) to the final location previously, bolt's position please refer to below, then fix the unit to the bolts.




## 3.4 Power cables connection

This chapter introduces how to wire AC IN/OUT cables to UPS in different modes, and UPS connecting with EBM/MBP.


### 3.4.1 Input /Output wiring specification

Before wiring UPS, upstream breaker and backfeed contactor should be configured to avoid power backfeed to unity. And 'backfeed voltage danger' warning label should be added in backfeed contactor or device. Before operating, UPS input should cut off, and check all terminals voltage to avoid voltage dangerous. Backfeed contactor rating current should be larger than UPS rating input current.

Below figures show the wiring system of UPS input.



Single phase input system



Three phase input system

**Danger!**

The rated current of the utility power switch must be greater than the UPS input current, otherwise the utility power switch may be burnt!

Recommended circuit breaker and contactor current specifications:

| UPS power rating | Input mode           | Breaker | Contactor |
|------------------|----------------------|---------|-----------|
| 10000VA          | 1 phase main input   | 80A     | ≥80A      |
|                  | 3 phase main input   | 32A     | ≥32A      |
|                  | 1 phase bypass input | 63A     | ≥63A      |
|                  | 3 phase bypass input | 32A     | ≥32A      |
| 15000VA          | 1 phase main input   | 125A    | ≥125A     |
|                  | 3 phase main input   | 50A     | ≥50A      |
|                  | 1 phase bypass input | 100A    | ≥100A     |
|                  | 3 phase bypass input | 50A     | ≥50A      |
| 20000VA          | 1 phase main input   | 160A    | ≥160A     |
|                  | 3 phase main input   | 63A     | ≥63A      |
|                  | 1 phase bypass input | 125A    | ≥125A     |
|                  | 3 phase bypass input | 63A     | ≥63A      |

Recommended output circuit breaker current specifications:

| UPS power rating | Output mode    | Breaker current |
|------------------|----------------|-----------------|
| 10000VA          | 1 phase output | 63A             |
|                  | 3 phase output | 32A             |
| 15000VA          | 1 phase output | 100A            |
|                  | 3 phase output | 50A             |
| 20000VA          | 1 phase output | 125A            |
|                  | 3 phase output | 63A             |

Recommended battery circuit breaker current specifications:

| UPS power rating | Breaker current |
|------------------|-----------------|
| 10000VA          | 80A             |
| 15000VA          | 63A             |
| 20000VA          | 80A             |



Read the Safety instructions regarding backfeed protection requirements.

Recommended cable minimum cross-sectional area (unit: mm<sup>2</sup>)

| UPS<br>power<br>rating | Input/<br>Output<br>Mode | Input         |        |                 |        |                | Output |        |                | Battery        |                |
|------------------------|--------------------------|---------------|--------|-----------------|--------|----------------|--------|--------|----------------|----------------|----------------|
|                        |                          | Main<br>input |        | Bypass<br>input |        | Ground<br>wire |        |        |                |                |                |
|                        |                          | L wire        | N wire | L wire          | N wire |                | L wire | N wire | Ground<br>wire | + /N/-<br>wire | Ground<br>wire |
| 10000<br>VA            | 3-3                      | 4             | 4      | 4               | 4      | 10             | 4      | 4      | 4              | 10             | 10             |
|                        | 3-1                      | 4             | 4      | 10              | 10     | 10             | 10     | 10     | 10             | 10             | 10             |
|                        | 1-1                      | 16            | 16     | 10              | 10     | 16             | 10     | 10     | 10             | 10             | 10             |
| 15000<br>VA            | 3-3                      | 6             | 6      | 6               | 6      | 10             | 6      | 6      | 6              | 10             | 10             |
|                        | 3-1                      | 6             | 6      | 16              | 16     | 16             | 16     | 16     | 16             | 10             | 10             |
|                        | 1-1                      | 35            | 35     | 16              | 16     | 35             | 16     | 16     | 16             | 10             | 10             |
| 20000<br>VA            | 3-3                      | 10            | 10     | 10              | 10     | 10             | 10     | 10     | 10             | 10             | 10             |
|                        | 3-1                      | 10            | 10     | 25              | 25     | 25             | 25     | 25     | 25             | 10             | 10             |
|                        | 1-1                      | 50            | 50     | 25              | 25     | 50             | 25     | 25     | 25             | 10             | 10             |

Note:

1. Please select the larger cross-section conductor for the UPS input cable in the single source application.
2. UPS output cable length is recommended not to exceed 10m.
3. In the three-phase output mode, if the load is an unbalanced load, the L wire of the bypass and output may exceed the rated current, and the maximum rated current will be 1.732 times. The corresponding protection device and wiring cable must be determined according to the standards of the region and the actual situation of the user.





### 3.4.2 Wiring for AC cable (AC source to UPS)

High leakage current:

Earth connection essential before connecting supply.




This type of connection must be carried out by qualified electrical personnel.

Before carrying out any connection, check that the upstream protection devices (Normal AC source and Bypass AC source) are open 'O' (Off).

Always connect the ground wire first.







Remove the cover of terminal block, Layout of AC input/output as below:




Note:

1. UPS input: PE/N/N/mL1/bL1/mL2/bL2/mL3/bL3('m' is main input, 'b' is bypass input)
2. UPS output: N/N/L1/L2/L3/PE

UPS provide busbars (as below) for 6 modes of wiring application, default is 3-3 mode (single source).

| Busbars |   | Mode                 |                    |                      |                    |                      |                    |
|---------|---|----------------------|--------------------|----------------------|--------------------|----------------------|--------------------|
| Item#   | Figure  | 3-3<br>Single source | 3-3<br>Dual source | 3-1<br>Single source | 3-1<br>Dual source | 1-1<br>Single source | 1-1<br>Dual source |
| 1       |    | 5pcs                 | 2pcs               | 2pcs                 | 2pcs               | 2pcs                 | 2pcs               |
| 3       |    |                      |                    | 1pc                  | 1pc                | 1pc                  | 1pc                |
| 4       |    |                      |                    | 1pc                  |                    |                      |                    |
| 5       |    |                      |                    |                      | 1pc                |                      | 1pc                |
| 6       |    |                      |                    |                      |                    | 1pc                  |                    |
| 7       |  |                      |                    |                      |                    |                      | 1pc                |

● Mode 3-3(single source)



Input: Connect ground cable (PE) to ground screw of chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Short terminal mL1/ bL1 with busbar #1, connect AC cable(L1);

Short terminal mL2/ bL2 with busbar #1, connect AC cable(L2);


Short terminal mL3/ bL3 with busbar #1, connect AC cable(L3).

Output: Connect ground cable (PE) to ground screw of chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Connect terminal L1/L2/L3 to AC cable(L1/L2/L3).

● Mode 3-3(dual source)



Input: Connect ground cable (PE) to ground screw of chassis first;


Short terminal N/N with busbar #1, connect AC main source cable(N) and bypass source cable(N);

Connect input terminal mL1/mL2/mL3 to main source cable(L1/L2/L3);

Connect bypass terminal bL1/bL2/bL3 to bypass source cable(L1/L2/L3).

Output: Connect ground cable (PE) to ground screw of chassis first;  
 Short terminal N/N with busbar #1, connect AC cable(N);  
 Connect terminal L1/L2/L3 to AC cable(L1/L2/L3).


● Mode 3-1(single source)



Input: Connect ground cable (PE) to ground screw of chassis first;  
 Short terminal N/N with busbar #1, connect AC cable(N);  
 Short input terminal mL1/bL1/bL2/bL3 with busbar #4, connect to AC cable(L1);  
 Connect terminal mL2 to AC cable(L2) and terminal mL3 to AC cable(L3).

Output: Connect ground cable (PE) to ground screw of chassis first;  
 Short terminal N/N with busbar #1, connect AC cable(N);  
 Short terminal L1/L2/L3 with busbar #3, connect AC cable(L).


● Mode 3-1(dual source)



Input: Connect ground cable (PE) to ground screw of chassis first;  
 Short terminal N/N with busbar #1, connect AC main source cable(N) and bypass source cable(N);  
 Connect input terminal mL1/mL2/mL3 to main source cable(L1/L2/L3);  
 Short bypass terminal bL1/bL2/bL3 with busbar #5, connect bypass source cable(L).

Output: Connect ground cable (PE) to ground screw of chassis first;  
 Short terminal N/N with busbar #1, connect AC cable(N);  
 Short terminal L1/L2/L3 with busbar #3, connect AC cable(L).


● Mode 1-1(single source)



Input: Connect ground cable (PE) to ground screw of chassis first;  
 Short terminal N/N with busbar #1, connect AC cable(N);  
 Short terminal mL1/bL1/mL2/bL2/mL3/bL3 with busbar #6, connect AC cable(L).

Output: Connect ground cable (PE) to ground screw of chassis first;  
 Short terminal N/N with busbar #1, connect AC cable(N);  
 Short terminal L1/L2/L3 with busbar #3, connect AC cable(L).

● Mode 1-1(dual source)



Input: Connect ground cable (PE) to ground screw of chassis first;  
 Short terminal N/N with busbar #1, connect AC main source cable(N) and  
 bypass source cable(N);

Short input terminal mL1/mL2/mL3 with busbar #7, connect main source cable(L);

Short bypass terminal bL1/bL2/bL3 with busbar #5, connect bypass source cable(L).

Output: Connect ground cable (PE) to ground screw of chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);


Short terminal L1/L2/L3 with busbar #3, connect AC cable(L).

### 3.4.3 Wiring with external battery modular (EBM) (DC source to UPS)




1. Be sure to disconnect the battery cable from the EBM before connecting the battery terminals of the UPS.
2. Make sure the UPS is completely off before connecting or disconnecting the EBM.
3. Before connecting the EBM, make sure that the EBM specifications is compatible with UPS configuration.
4. Do not reverse the polarity of the external battery.

EBM wiring schematic diagram is shown below:




Single set of EBM



Multiple sets of EBM

- Connect with the configured EBM:  
Connect EBM to UPS with 'Battery cable' and 'EBM detect cable'.

## EBM




**Note:** EBM automatic detection function supports up to 3 EBMs for Tower 10kVA UPS. For more EBM quantity (max to 6), need configure the battery capacity in LCD.

Extended runtime with up to 6 EBMs for each Tower 15/20kVA UPS.

- Connect with user's own EBM:

Connect user's own EBM to UPS with 'Battery cable' (if configured).






## 3.5 Gland kit installation

Before Gland kit installation, select the appropriate cables according to the wiring table in section 3.4.2

1. Open the terminal block cover
2. Assemble the glands and cables to the gland bracket according to input/output Mode & Connect the wires of cables to the terminal block/busbar according section 3.4.2.
3. Re-lock the terminal block cover back




## 4. Parallel System Installation and Operation (Optional)

If your UPS is configured with parallel function, up to 3 UPS can be connected in parallel for power parallel or N+1 redundancy.

In parallel system, the mechanical installation for each modular is same as the single system. Details please refer to Chapter 3.3.

Parallel system AC cable diagram:



### 4.1 Wiring for AC/DC cable



#### 1. Wiring length requirement:

When the distance between the load and the parallel UPS is less than 10 meters, the length difference between the input/output lines between the UPSs in the parallel system is less than 20%.

When the distance between the load and the parallel UPS is greater than 20 meters, the length difference between the input/output lines between the UPSs in the parallel system is less than 5%.

#### 2. Professional installation is required, please set the parallel system in the restricted area!

This chapter introduces how to wire AC IN/OUT cable to UPS in parallel system, and UPS connecting with EBM/MBP.

#### 4.1.1 Input /Output wiring specifications

Cable-select table for the parallel system AC IN, AC OUT and Battery wire:

| Parallel system installed by 10kVA UPS (conductor cross-section, unit: mm <sup>2</sup> ) |      |            |        |              |        |             |        |        |        |              |                |
|--|------|------------|--------|--------------|--------|-------------|--------|--------|--------|--------------|----------------|
| UPS number   | Mode | Main input |        | Bypass input |        | Ground wire | Output |        |        | Battery wire | Battery ground |
|  |      | L wire     | N wire | L wire       | N wire |             | L wire | N wire | Ground |              |                |
| 2 UPS  | 3-3  | 10         | 10     | 6            | 6      | 10          | 6      | 6      | 6      | 35           | 35             |
|  | 3-1  | 10         | 10     | 25           | 25     | 25          | 25     | 25     | 25     | 35           | 35             |
|  | 1-1  | 50         | 50     | 25           | 25     | 50          | 25     | 25     | 25     | 35           | 35             |
| 3 UPS  | 3-3  | 16         | 16     | 10           | 10     | 16          | 10     | 10     | 10     | 70           | 70             |
|  | 3-1  | 16         | 16     | 50           | 50     | 50          | 50     | 50     | 50     | 70           | 70             |
|  | 1-1  | 95         | 95     | 50           | 50     | 95          | 50     | 50     | 50     | 70           | 70             |
| Parallel system installed by 15kVA UPS (conductor cross-section, unit: mm <sup>2</sup> ) |      |            |        |              |        |             |        |        |        |              |                |
| UPS number   | Mode | Main input |        | Bypass input |        | Ground wire | Output |        |        | Battery wire | Battery ground |
|  |      | L wire     | N wire | L wire       | N wire |             | L wire | N wire | Ground |              |                |
| 2 UPS  | 3-3  | 16         | 16     | 10           | 10     | 16          | 10     | 10     | 10     | 25           | 25             |
|  | 3-1  | 16         | 16     | 50           | 50     | 50          | 50     | 50     | 50     | 25           | 25             |
|  | 1-1  | 95         | 95     | 50           | 50     | 95          | 50     | 50     | 50     | 25           | 25             |
| 3 UPS  | 3-3  | 35         | 35     | 16           | 16     | 35          | 16     | 16     | 16     | 50           | 50             |
|  | 3-1  | 35         | 35     | 95           | 95     | 95          | 95     | 95     | 95     | 50           | 50             |
|  | 1-1  | 185        | 185    | 95           | 95     | 185         | 95     | 95     | 95     | 50           | 50             |
| Parallel system installed by 20kVA UPS (conductor cross-section, unit: mm <sup>2</sup> ) |      |            |        |              |        |             |        |        |        |              |                |
| UPS number   | Mode | Main input |        | Bypass input |        | Ground wire | Output |        |        | Battery wire | Battery Ground |
|  |      | L wire     | N wire | L wire       | N wire |             | L wire | N wire | Ground |              |                |
| 2 UPS  | 3-3  | 25         | 25     | 16           | 16     | 25          | 16     | 16     | 16     | 35           | 35             |
|  | 3-1  | 25         | 25     | 70           | 70     | 70          | 70     | 70     | 70     | 35           | 35             |
|  | 1-1  | 120        | 120    | 70           | 70     | 120         | 70     | 70     | 70     | 35           | 35             |
| 3 UPS  | 3-3  | 50         | 50     | 25           | 25     | 50          | 25     | 25     | 25     | 70           | 70             |
|  | 3-1  | 50         | 50     | 150          | 150    | 150         | 150    | 150    | 150    | 70           | 70             |
|  | 1-1  | 240        | 240    | 150          | 150    | 240         | 150    | 150    | 150    | 70           | 70             |


Note:

1. Please select the larger cross-section conductor for the parallel system 'AC IN cable' in the single source application.
2. In the three-phase output mode, if the load is an unbalanced load, the L wire of the bypass and output may exceed the rated current, and the maximum rated current will be 1.732 times. The corresponding protection device and wiring cable must be determined according to the standards of the region and the actual situation of the user.


#### 4.1.2 Wiring for AC cable (AC source to UPS)

AC cable wiring are shown in below diagrams for different configuration.


- 3-3 configuration (single source)




- 3-3 configuration (dual source)




- 3-1 configuration (single source)




- 3-1 configuration (dual source)



- 1-1 configuration (single source)



- 1-1 configuration (dual source)




#### 4.1.3 Wiring with external battery modular (EBM) (DC source to UPS)

- **Parallel UPS connection with 'independent battery'**

In the parallel system, independent EBM connect to each UPS please refer to chapter 3.4.3.

- **Parallel UPS connection with 'common battery'**

In the parallel system, you can also set up 'common battery' (user's own battery) for all UPSs. Please refer to below diagram for battery wiring.




**Note:** Common battery configuration is not suitable for standard model.




## 4.2 Wiring for parallel signal cable

Parallel system 'parallel cable' diagram:






Connect each UPS one by one with 'parallel cable', make sure the cable is screwed to parallel port tightly.



It is recommended to lock the 'parallel cable' (as above) for preventing the parallel ports suffering an unexpected pulling-force and causing the parallel system fault.

## 4.3 Parallel system operation

1. Turn on the input breakers for the parallel UPS.
2. Pressing  button continuously for one UPS of the system, then the system will start to turn on and enter line mode.
3. Regulate the output voltage of each UPS separately, and check if the output voltage difference is less than 0.5V among the parallel system. If the difference is more than 0.5V, the UPS need to be regulated.
4. If the output voltage difference is less than 0.5V, pressing  button continuously for one UPS of the system to turn off the system. Turn off the input breakers to let UPS shut down. Then switch on the output breakers for all the UPS.
5. Turn on the input breakers for the parallel UPS. Pressing  button continuously for one UPS of the system, then the system will start to turn on and enter line mode and the system will work normally in parallel.







# 5. Operation

## 5.1 LCD panel


The UPS has a touch graphical LCD. It provides useful information about the UPS itself, load status, events, measurements and settings.



### The LED:

| LED status  | description  | UPS status  |
|---|--------------|---|
|    | Red on       | Fault mode  |
|    | Red flash    | General alarm                                       |
|    | Yellow on    | Battery mode  |
|    | Yellow flash | Bypass mode with output                             |
|  | Green on     | Line mode or HE mode                                |
|  | off          | No output (power on/shutdown/bypass without output) |


### The button:

| button  | function | description  |
|---|----------|--|
|  | On/off   | When only battery power is available, press to power on<br>When UPS is not turned on, pressing this key to turn on<br>When working normally, press to pop up the shutdown page<br>When the UPS is in fault mode, press to clear the fault (some faults cannot be cleared directly) |













**The Buzzer :**

| The buzzer             | General Meaning   |
|------------------------|---|
| 1 beep every 2 minutes | Load supplied on bypass                                       |
| 1 beep every 4 seconds | Load supplied on battery<br>If battery low, beep every second |
| 1 beep every second    | General warning active  |
| 2 beeps every second   | Overload warning  |
| Continuous             | Fault active  |
| Only beep              | Touch screen operation sound                                  |


## 5.2 LCD description



| Display Area    | Icon                              | Description  |
|-----------------|-----------------------------------|--|
| Battery status  | 100%<br>126min                    | Battery capacity<br>Backup time  |
| UPS mode        | <b>Line Mode</b>                  | The work mode of the UPS   |
| Load percentage | 50%<br>50% L1<br>50% L2<br>50% L3 | When it is 3 phase output, the load for each of the 3 phases is displayed in this area |

| Display Area                    | Icon  | Description   |
|---------------------------------|---|---|
| Bypass status and measurements  |   | <p>Different icon shows the phase number of bypass</p> <p>Click on this icon will bring up a popup of measurements of the bypass</p>  |
| Battery status and measurements |    | <p>Click on this icon will bring up a popup of measurements of the battery</p>  |
| Line status and measurements    |   | <p>Different icon shows the phase number of Utility</p> <p>Click on this icon will bring up a popup of measurements of the utility</p>  |
| Output status and measurements  |   | <p>Different icon shows the phase number of output</p> <p>Click on this icon will bring up a popup of measurements of the output</p>  |
| Energy flow chart               |   | <p>The sick solid line means there is energy flow, the double thin line means nothing</p>   |
| System time                     |    | <p>It can be set in user settings</p>   |
| Menu icon                       |    | <p>Click on this icon can entry the menu screen</p>   |
| Alarm area                      |    | <p>When UPS enters fault mode, fault ICON and the fault information will be displayed.</p> <p>If alarms exist, alarm information will scroll for up to 4 messages, each for 2 seconds</p> |
| Para ID                         |    | <p>The UPS ID number in parallel system (1-3), keep 1 in single mode</p>  |

## 5.3 Menu structure



## 5.4 Control and product information

| Main menu    | Submenu                 | Menu function                                    |
|--------------|-------------------------|--|
| Control      | Battery test            | Starts a manual battery test in stand-alone mode |
|              | Battery test (Parallel) | Starts a single battery test in parallel mode    |
|              | Reset fault             | Clear active fault                               |
|              | Reset factory setting   | Restore to default factory settings              |
|              | Single UPS shutdown     | Operate this machine to exit parallel connection |
| Product Info | UPS model               | Model name & input/output phase                  |
|              | Serial number           | Serial number of UPS                             |
|              | UPS firmware version    | Version of UPS firmware                          |
|              | LCD firmware            | Version of UI                                    |
|              | JHD-APP version         | Version of LCD driver                            |

## 5.5 User settings

| Setting |                                  | Options on the display   | Default     |
|---------|----------------------------------|--|-------------|
| General | Audible Alarm                    | [Enabled], [Disabled]  | Enabled     |
|         | Date/Time                        | YYYY-MM-DD HH:MM   | 2020-1-1    |
|         | Language                         | English, Italiano, Français, Deutsch, Español, Русский, Polski, 简体中文 | English     |
|         | LCD brightness                   | [0%-100%]  | 100%        |
|         | LCD saving mode                  | [Enabled], [Disabled]  | Enabled     |
|         | Screen rotation                  | [Auto Rotate], [Horizontal], [Vertical]                              | Auto Rotate |
| Input   | Site wiring fault <sup>(1)</sup> | [Enabled], [Disabled]  | Disabled    |
|         | Bypass voltage low limit         | 110 ~ (V <sub>inverter</sub> - 15V)                                  | 187V        |
|         | Bypass voltage high limit        | (V <sub>inverter</sub> + 15V) ~ 276V                                 | 264V        |
|         | Bypass frequency low limit       | -10%~-5%   | -10%        |
|         | Bypass frequency high limit      | 5%~10%   | 10%         |
|         | HE voltage low limit             | -15%~-5%   | 10%         |

|               |                            |  |                       |
|---------------|----------------------------|--|-----------------------|
|               | HE voltage high limit      | 5%~20%   | 10%                   |
|               | HE frequency low limit     | -10%~-5%   | 5%                    |
|               | HE frequency high limit    | 5%~10%   | 5%                    |
|               | Dual input function        | [Enabled], [Disabled]  | Disabled              |
| Output        | UPS Mode                   | [Normal mode], [HE mode], [CVCF mode]  | Normal mode           |
|               | Output voltage             | [220V], [230V], [240V]   | 230V                  |
|               | Output frequency           | [Auto detection], [50Hz], [60Hz]   | Auto detection        |
|               | ESS function               | [Enabled], [Disabled]  | Disabled              |
|               | Auto bypass                | [Enabled], [Disabled]  | Enabled               |
|               | Auto restart               | [Enabled], [Disabled]  | Enabled               |
|               | Short circuit auto clear   | [Enabled], [Disabled]  | Disabled              |
|               | Overload pre-alarm         | 50%~105%   | 105%                  |
| Battery       | DC Start                   | [Enabled], [Disabled]  | Enabled               |
|               | Battery Auto Test          | [Every cycle] [Disabled]   | Every cycle           |
|               | Deep discharge protection  | [Enabled], [Disabled]  | Enabled               |
|               | Low bat warning            | 0%~100%  | 0%                    |
|               | Low remaining time warning | 0~999min   | 0min                  |
|               | Restart battery level      | 0~100%   | 0%                    |
|               | Charger current            | [1~13A] for 10~20K   | Default 1.8A          |
|               | External battery setting   | [Auto detection], [Manual AH setting]<br>Manual AH setting: [9~300AH]          | [Auto detection]<br>/ |
| Communication | Dry in                     | [No function] [Start UPS]<br>[Remote shut down]<br>[Maintenance bypass]        | No function           |
|               | Dry out                    | [load powered] [on battery]<br>[Low battery] [No Battery]<br>[Bypass] [ups OK] | load powered          |
| Password      | Control Menu password      | [Enabled], [Disabled]  | Enabled               |
|               | Setting Menu password      | [Enabled], [Disabled]  | Enabled               |
|               | Change Password            | Old password<br>New password<br>Confirm password                               | [4732]                |

(1) Site wiring fault function is only for single phase bypass input. If the utility power is IT system, the site wiring fault function should be disabled.



## 5.6 Starting the UPS with utility

Startup preparation:




Before startup the UPS, please make sure that the wiring is securely connected, otherwise there is a danger of electric shock.

- Verify that the total UPS output load does not exceed the rated capacity of the UPS.
- The wiring of the UPS input and output is correctly connected according to the required mode.
- Confirm that the UPS output device is not started.
- Make sure the UPS is reliably connected to the battery.
- Connect communication interfaces that need to be used.

### **Startup the UPS with utility power:**

1. Turn on input breaker and output breaker.
2. The fan starts to rotate, the LCD displays startup animation, then enters the main page.
3. UPS default Bypass enable, the main page shows UPS working in bypass mode.
4. The default input/output mode is three-input and three-out. If it is inconsistent with the actual wiring, it needs to be changed to the actual wiring mode.
5. Press the button for more than 1 second, the buzzer will beep and the UPS will start up. After a few seconds, the UPS will go to normal mode.



6. If the utility power is abnormal, the UPS will transfer to Battery mode.
7. When the battery is not connected, the UPS can still be startup. After the startup, there is alarm of battery not connected. If the utility power is abnormal, the UPS load will not be protected.

8. The load is powered by the UPS and the LCD shows a charging sign indicating that the battery is charging.
9. Startup the output device.



If you want to cancel the Bypass enable function, please refer to chapter “User setting”.

The input/output mode is modified by the service personnel:

1. Pull out the RPO connector.
2. Turn on input breaker, check the UPS mode in the LCD. If it is different from the actual wiring mode, change to the actual wiring mode.
3. Power off the UPS completely. Then power on, confirm that the mode is set correctly.
4. Power off the UPS again, insert the RPO terminal.

## 5.7 Starting the UPS on battery



Before using this feature, the UPS must have been powered by utility power with output enabled at least once.

Battery start can be disabled. See the "DC start" setting in "Battery/DC Start".

To start the UPS on battery:

1. Press the button for more than 0.1 seconds. The UPS establishes the power, the fan starts to rotate, the LCD displays the startup animation, and then enters the main page to display the standby mode.
2. If there is no operation, the LCD is off out after 10 seconds and the UPS is powered down.
3. Press the button for more than 1 second, the buzzer will beep and the UPS will startup. The UPS will go to battery mode after a few seconds.
4. If the utility power is connected at this time, the UPS will switch to the line mode and the output will be uninterrupted.
5. UPS works in battery mode, and the buzzer beep for 4 seconds to remind that the battery is discharged.
6. Since there is no utility power input, the input abnormal alarm will be displayed on the LCD.

## 5.8 UPS shutdown

Shutdown the UPS with utility power mode:

1. UPS working with utility power, press the button for more than 3s, the LCD pops up to confirm the shutdown page.
2. After clicking Confirm, the UPS performs shutdown.
3. After shutdown, the UPS works in bypass mode and the output remains powered.
4. If there is no need the UPS output, disconnect the input utility power.

Shutdown the UPS with battery mode:

1. Press the button for more than 3s, the LCD pops up to confirm the shutdown page;
2. After clicking Confirm, the UPS performs shutdown.
3. The UPS output is interrupted and goes into standby mode. After a few seconds, the UPS automatically shuts down.

# 6 Communication

## 6.1 RS232 and USB

- 1. Communication cable to the serial or USB port on the computer.
- 2. Connect the other end of the communication cable to the RS232 or USB communication port on the UPS.

## 6.2 UPS remote control functions


- **Remote Power Off (RPO)**

When RPO is activated, UPS will cut off output immediately, and continues to alarm.

| RPO                            | Comments                  |
|--------------------------------|---------------------------|
| Connector type                 | 16 AWG Maximum wires      |
| External breaker specification | 60 V DC/30 V AC 20 mA max |

Reset:


- 1. Check the RPO connector status;
- 2. Clear fault state through LCD.



- **Dry in**

Dry in function can be configured. (see Settings > Dry in)


| Dry in                         | Comments                  |
|--------------------------------|---------------------------|
| Connector type                 | 16 AWG Maximum wires      |
| External breaker specification | 60 V DC/30 V AC 20 mA max |



- **Dry out**

Dry out is the relay out, dry out function can be configured. (See Settings > Dry out)

| Dry out                   | Comments             |
|---------------------------|----------------------|
| Connector type            | 16 AWG Maximum wires |
| Inner Relay specification | 24Vdc/1A             |



# 7 UPS Maintenance

## 7.1 Equipment care

For the best preventive maintenance, keep the area around the equipment clean and dust free. If the atmosphere is very dusty, clean the outside of the system with a vacuum cleaner.

For full battery life, keep the equipment at an ambient temperature of 25°C (77°F).



The batteries are rated for a 3-5 years expected life. The service life varies, depending on the frequency of usage and ambient temperature. Batteries used beyond expected service life will often have severely reduced runtimes. Replace batteries at least every 4 years to keep units running at peak efficiency.

## 7.2 Transporting the UPS



Please transport the UPS only in the original packaging. If the UPS requires any type of transportation, verify that the UPS is disconnected and turned off.

## 7.3 Storing the equipment

If you store the equipment for a long period, recharge the battery every 6 months by connecting the UPS to utility power. Recommends that the batteries charge for 48 hours after long-term storage.

If batteries were never recharged over 6 months, do not use them. Contact your service representative.

## 7.4 Recycle



Contact your local recycling or hazardous waste center for information on proper disposal of the used equipment.

Do not dispose of the batteries in the fire. Which may cause battery explosion. The batteries must be rightly disposed according to local regulation.

Do not open or destroy the batteries. Escaping electrolyte can cause injury to the skin and eyes. It may be toxic.



**Pb**



Do not discard the UPS or the UPS batteries in the trash.

This product contains sealed lead acid batteries and must be disposed as it's explained in this manual. For more information, contact your local recycling/reuse or hazardous waste center.

The crossed-out wheeled bin symbol indicates that waste electrical and electronic equipment should not be discarded together with unseparated household waste but must be collected separately. The product should be handed in for recycling in accordance with the local environmental regulations for waste disposal.

By separating waste electrical and electronic equipment, you will help reduce the volume of waste sent for incineration or land-fills and minimize any potential negative impact on human health and environment.

# 8 Troubleshooting



The UPS is designed for durable, automatic operation and also alert you whenever potential operating problems may occur. Usually the alarms shown by the control panel do not mean that the output power is affected. Instead, they are preventive alarms intended to alert the user.

- Events are silent status information that are recorded into the Event log. Example = "Battery charging".
- Alarms are recorded into the Event log and displayed on the LCD status screen with the logo blinking. Some alarms may be announced by a beep every 1 second. Example = "Battery low".
- Faults are announced by a continuous beep and red LED, recorded into the Event log. Example = Output short circuit.


Use the following troubleshooting chart to determine the UPS alarm condition.

## 8.1 Typical alarms and faults


To check the fault log or event log:



Click on **"Menu"** icon



Click on **"History"** icon




Click on **"Fault"** icon

Last 5 faults, blank list if no fault



| No. | ID# | List                 | Date                |
|-----|-----|----------------------|---------------------|
| 1   | 000 | Output Short Circuit | 2019-12-01 12:12:12 |
| 2   | 000 | Output Short Circuit | 2019-12-01 12:12:12 |
| 3   | 000 | Output Short Circuit | 2019-12-01 12:12:12 |
| 4   | 000 | Output Short Circuit | 2019-12-01 12:12:12 |
| 5   | 000 | Output Short Circuit | 2019-12-01 12:12:12 |





Click on “Event” icon

Last 100 events



If alarm exists, shows here. 4 messages for high priority alarm


| Problem Displayed   | Possible cause  | Remedy  |
|---------------------|---|---|
| Site wiring fault   | Phase and neutral conductor at input of UPS system are reversed | Reverse mains power wiring  |
| Neutral wire missed | Neutral abnormal  | Confirm the connection of the input wires   |
| Pos Bat open        | Battery pack is not connected correctly                         | Do the battery test to confirm; Check the battery bank is properly connected to the UPS; Check the battery breaker is turn on or fuse OK  |
| Neg Bat open        | Battery pack is not connected correctly                         | Do the battery test to confirm; Check the battery bank is properly connected to the UPS; Check the battery breaker is turn on or fuse OK. |
| Pos Bat Low         | Battery voltage is low  | When audible alarm sounding every second, battery is almost empty   |
| Neg Bat Low         | Battery voltage is low  | When audible alarm sounding every second, battery is almost empty.  |
| Pos Over Charge     | Battery voltage is high   | Consult Service   |
| Neg Over Charge     | Battery voltage is high   | Consult Service   |
| Pos Charger Failure | UPS internal fault  | Consult Service   |

| Problem Displayed        | Possible cause  | Remedy  |
|--------------------------|---|---|
| Neg Charger Failure      | UPS internal fault  | Consult Service   |
| Bad Battery Count        | Unreasonable battery number   | Check whether the actual battery cell number is consistent with the set value   |
| Pos Bus Over Volt        | UPS internal fault, the + DC BUS voltage is too high                                | Consult Service   |
| Neg Bus Over Volt        | UPS internal fault, the -DC BUS voltage is too high                                 | Consult Service   |
| Pos Bus Under Volt       | UPS internal fault, the + DC BUS voltage is too low                                 | Consult Service   |
| Neg Bus Under Volt       | UPS internal fault, the -DC BUS voltage is too low                                  | Consult Service   |
| Bus Unbalance            | UPS internal fault, the voltage difference between DC Bus+ and DC bus- is too large | Consult Service   |
| Bus Short                | UPS internal fault  | Consult Service   |
| Bus Soft Start Fail      | UPS internal fault  | Consult Service   |
| Output Short circuit     | abnormally low impedance placed on its output and considers it a short circuit      | Remove all the loads. Turn off the UPS;<br>Check if UPS output and loads is short circuit;<br>Ensure short circuit is removed before turning on again |
| L1 Output Short circuit  |   |   |
| L2 Output Short circuit  |   |   |
| L3 Output Short circuit  |   |   |
| Inverter Over Volt       | UPS internal fault, the inverter voltage is too high                                | Consult Service   |
| Inverter Under Volt      | UPS internal fault, the inverter voltage is too low                                 | Consult Service   |
| Inverter Soft start Fail | UPS internal fault  | Consult Service.  |
| Inverter Overload Fault  | Overload  | Check the loads and remove some noncritical loads;<br>Check if some loads are failed  |
| Output Overload Fault    |   |   |
| Byp Overload Fault       |   |   |
| Inverter Capacity Open   | UPS internal fault  | Consult Service   |
| Primary SPS Fail         | UPS internal fault  | Consult Service   |
| Assist SPS Fail          |   |   |
| Emergency Off            | Perform emergency shutdown  | Check the status of RPO terminal  |
| Internal Over Temp Fault | Inside temperature of UPS is too high   | Check the ventilation of UPS and the ambient temperature  |
| Byp SCR Over Temp        |   |   |
| Charger Over Temp Fault  |   |   |
| UPS Ambient Over Temp    | The ambient temperature is too high   | Check the environment ventilation   |
| Fan Lock                 | Fan abnormal  | Check if the fan is running   |


| Problem Displayed   | Possible cause             | Remedy  |
|---------------------|----------------------------|---|
| ESS Fan lock        |                            | normally or fan detection cable disconnected                                    |
| Model Setting Wrong | Wrong work mode            | Consult Service   |
| Neg Power Fault     | Negative power fault       | Consult Service   |
| Para. Cable Lost    | The cable is not connected | Please confirm the connection status of the parallel cable                      |
| Para. Incompatible  | Para setting different     | Please check the parallel settings, if it still alarms, please consult Service. |

# 9 Troubleshooting

## 9.1 UPS block diagram



## 9.2 UPS specification

| Models                     |   | 10K  | 15K        | 20K        |
|----------------------------|---|--|------------|------------|
| Rated power <sup>(1)</sup> |   | 10kVA/10kW   | 15kVA/15kW | 20kVA/20kW |
| Rated frequency            |   | 50/60Hz  |            |            |
| Input                      | Voltage range (Phase voltage)                     |  <p>100~300VAC</p> |            |            |
|                            | Rated voltage (Phase voltage)                     | 220/230/240VAC   |            |            |
|                            | Main input Rated current <sup>(2)</sup> (3 Phase) | 22A  | 35A        | 43A        |
|                            | Main input Rated current <sup>(2)</sup> (1 Phase) | 65A  | 105A       | 129A       |
|                            | Bypass input Rated current (3 Phase)              | 16A  | 24A        | 31A        |

| Models                          |  | 10K  | 15K                  | 20K                 |
|---------------------------------|--|--|----------------------|---------------------|
| Input                           | Bypass input<br>Rated current<br>(1 Phase)                     | 47A  | 70A                  | 93A                 |
|                                 | Main input<br>frequency for 3-3 and 3-1 mode                   | 40-70Hz  |                      |                     |
|                                 | Main input<br>frequency for 1-1 mode                           | ≤60% rated load: 40-70Hz   |                      |                     |
|                                 |  | > 60% rated load <sup>(1)</sup> : 45-55Hz(50Hz system) / 54-66Hz (60Hz system)   |                      |                     |
|                                 | Bypass Input<br>frequency                                      | 45-55Hz (50Hz system) / 54-66Hz (60Hz system)  |                      |                     |
| Charging current <sup>(1)</sup> |  | 1~13A adjustable for 10-20K;   |                      |                     |
| Charging current (default)      |  | 1.8A   | 1.8A                 | 1.8A                |
| Output                          | Rated voltage<br>(Phase voltage)                               | 220/230/240VAC   |                      |                     |
|                                 | Overload   | 105%-125% Load, 10 minutes transfer to Bypass;<br>125%-150% Load, 30 seconds transfer to Bypass;<br>>150% Load, 0.5 seconds transfer to Bypass |                      |                     |
|                                 | Short-circuit<br>current on normal<br>mode<br>(3 Phase output) | 30A for 10±1 cycle   | 56.8A for 10±1 cycle | 74A for 10±1 cycle  |
|                                 | Short-circuit<br>current on normal<br>mode<br>(1 Phase output) | 90A for 10±1 cycle   | 171A for 10±1 cycle  | 222A for 10±1 cycle |
| Transfer Time Line<->Battery    |  | 0ms  |                      |                     |
| Transfer Time INV<->Bypass      |  | 0ms  |                      |                     |
| Battery                         |  |  |                      |                     |
| Battery Voltage                 |  | 2*120VDC   | 2*240VDC             |                     |
| Battery Number                  |  | 2*10PCS  | 2*20PCS              |                     |
| Environment                     |  |  |                      |                     |
| Ambient temperature             |  | 0°C ~ 50°C (Derating 50% above 40°C)   |                      |                     |
| Relative humidity               |  | 0 ~ 95% (no condensing)  |                      |                     |
| Operating altitude              |  | <4000m (Derating use above 1km)  |                      |                     |

| Models                                   | 10K            | 15K | 20K |
|--|----------------|-----|-----|
| Storage temperature<br>(with battery)    | -15°C ~ 40°C   |     |     |
| Storage temperature<br>(without battery) | -25°C ~ 60°C   |     |     |
| Criterion                                |                |     |     |
| Safety                                   | IEC/EN 62040-1 |     |     |
| EMC                                      | IEC/EN 62040-2 |     |     |
| Performance                              | IEC/EN 62040-3 |     |     |

- (1) In CVCF mode or dual source input mode, UPS needs to be de-rated to 60% capacity for 1-1 mode (rated output power and maximum charging current).
- (2) @ 220VAC input phase voltage, rated output power and maximum charging.

Certificate of guarantee

Model:

Serial number:

Date of purchase:

Trading stamp / Signature

Specifications are subject to change without notice

Operating instructions  
BAL 8000071791, EN

**AEG Power Solutions**

Email-Siepmann-Str. 32 | 59581 Warstein-Belecke | Germany | Tel. +49 180 523 4787 | Fax +49 180 523 4789 | [www.aegps.com](http://www.aegps.com)

AEG PS – Technical data in this document does not contain any binding guarantees or warranties. Content only serves for information purposes and can be modified at any time. We will make binding commitments only upon receipt of concrete enquiries and customer notification of the relevant conditions. Due to the non-binding nature of these terms, we assume liability neither for the accuracy nor completeness of the data provided here. Product made in China. AEG is a registered trademark used under license from AB Electrolux.