



Generating Set Diesel - Electric start up

GE.ECHO 070 Y DT AE



🚺 Technical data

Standard voltage	V	230	400
Power	kVA	4*	7
Active power	kW	3,2	5,6
Speed	rpm	30	00
Frequency	Hz	5	0
Current	А	14	10
Voltage accuracy	V	+/- 5%	
Frequency accuracy	Hz	+/-	4%

 * Not to be taken simultaneously with the three-phase power.

🗟 General data

C	-	
Start-up	Туре	Electric
Sound pressure level @ 7 mt	dbA	74
Tank	Lt	6
Fuel consumption @ 4/4 load	Lt/H	1,5
Battery capacity (recommended)	Ah	45
Exhaust pipe diameter	Мт	40
Dimensions (LxWxH)	Мт	760 x 520 x 690
Dry weight	Kg	122

🛛 Engine

Brand	-	YANMAR
Model	-	L 100
Cooling	Туре	Air
Cycle	Туре	Diesel 4-stroke
Mechanical power	KWm	6,5
No cylinders / arrangement	-	1-L
Brore x stroke	Мm	86 x 75
Displacement	Cm ³	435
Speed governor	Туре	Mechanical

Alternator

Phases	-	3 + N
Degree of protection	-	IP21
Cooling	-	Air forced
Voltage regulator	Туре	Condenser
Waveform distortion	%	<5

Environmental conditions

Temperature	°C	25	
Relative humidity	%	30	
Maximum altitude	Mt	1000	



	EQUIPA	MENT
Protective cover		
Forklift chassis with integrated anti-tip		integrated anti-tip
	Raised c	hassis
	Easy sta	irt-up
Alternato	or stabilized,	high performance
Hand	lle for short	displacements
	Start ba	ittery
	Easy main	tenance
Ant	i-vibrating n	nounting pads
CON	TROL PANE	EL ON BOARD
n.1 CEE socket 16	\ 2P + T	
n.1 CEE socket 16 A		
Thermal circuit bre	aker	
LED Voltmeter		
Hourcounter		
Magnetothermal		
Protection system		
electrical separation		ITATION
Lleon	DOCUMEN	-
		nance manual
ECI	OPTION OPTION	of Conformity
r		
E	Off road tr	<u> </u>
Dom		rom 20 to 50m.
Kenno	Additional	
Remoter		nector: O.G-CNA-01
		vitch + GS interface:
Automati	QA.MPE	
	The QAM	PE panel permits the control
	and the m	nanagement of the
	5	ng sets in case of emergency main. It controls the main, the
		nd the battery and
	5	s in case of necessity.
	to the state of	and the standard state in a second



CE

RoHS Compliant The QAMPE panel permits the control and the management of the generating sets in case of emergency with the main. It controls the main, the engine and the battery and intervenes in case of necessity. It is also provided with a manual command in case of electronic breakdown that keeps active the protections of the generating set. It get ready for remote control and is equipped with a powerful and precise battery charger.