





#### Generating Set SUPERSILENT - diesel

# GE.AI.131/120.SS+011

1500 rpm - Threephase - 50Hz - 400V Automatic Panel with AMF without ATS



#### Image for demonstration purposes

### **Standard equipment**

#### Canopy Soundproofing

Soundproofing with class 1 polyester material Handles with key lock and automatic closing Special baffles for air intake and air expulsion Inspection doors for controls and maintenance

### Exhaust

Exhaust rain cap Exhaust manifold protection Insulated exhaust pipes Internal residential muffler - 35dB(A)

#### Fuel Supply

Single wall daily tank with bunded base Automatic shutdown system for low fuel level Fuel gauge

#### Handling

Lifting hook integrated into the bearing structure Base frame with anti-overturning forklift pockets

#### Base Frame

Bunded base at 110% of fuel tank capacity Anti-vibrating mounting pads Battery compartment externally accessible for easy service

### C Engine

Engine pre-heater 230v High coolant temperature and low oil pressure shutdown system Oil pressure and coolant temperature gauge (only with qpe or +14 variant) External oil drain points Engine liquids (oil and antifreeze) Tropicalized radiator Rotating parts protection

#### Alternator

Avr automatic voltage regulator Impregnation for marine environment Ip23

#### Panel & connection

Emergency stop button Magnetothermal circuit breaker on alternator board Tamperproof panel ip55 Cable output from side Ip44 wiring Start-up battery (pre-charged) Grounding point

#### Documentation

Ce conformity declaration User and maintenance manual Wirings diagrams

#### Normatives

All generating sets are compliant to CE marking 2014/30/UE electromagnetic compatibility 2000/14/CE noise emission for outdoor use Factory-designed systems built according to ISO 9001:2015 CEI EN 60204-1:2018 - Electrical equipment of machines







# **Primary data**

Speed	RPM	1500
Frequency	Hz	50
PRP	KVA	120
Prp - prime power	KW	96,0
Ltp - standby power	KVA	135
 Ltp - standby power	KW	108,0
Standard voltage	V	400/230
Current	А	173,4
Cosfi	0,8	0,8
General electrical protection		
Circuit-breaker rated current	Α	250
Туре		Magnetothermal switch on the alternator board
Circuit-breaker poles	Ν	4P
Noise level +/- 3dB(A)		
LWA	dB(A)	91
Sound pressure level @ 7 mt	dB(A)	66
Sound pressure level @ 1 mt	dB(A)	75
Fuel Consumption		
Туре		diesel
Standard fuel tank capacity	lt	400
Autonomy @ 75% load	h	19
Fuel consumption at 100% load	lt/h	27,6
Fuel consumption at 75% load	lt/h	21,6
Fuel consumption at 50% load	lt/h	14,4
General data		
Rated capacity	Ah	1x120
Auxiliary voltage	V	12
Exhaust gas temperature	°C	540
Combustion air flow	l/s	118,6
Cooling fan airflow	mc/s	2,2
Exhaust diameter	тт	100
Weight and Dimensions		
Dimensions (l x w x h)	ст	320x120x190
Weight with liquids (excluding optionals and fuel)	Kg (+/-3%)	1987





# Engine

Factory		FPT
Model		N45TM3
Emissions stage		Stage 0
Speed governor		Mechanic
Radiator	°C	50
Cooling	Тіро	liquid (water + 50% Paraflu11)
Active net power	Kwm	107
Nominal net power	CV	145,4
Cycle	Тіро	4 strokes
Injection	Тіро	Direct
Aspiration	Тіро	Turbo
Numbers of cylinders	Ν	4
Cylinders arrangement		L
Bore	mm	104
Stroke	mm	132
Total displacement	lt	4,483
Engine oil features		15W40-API CI-4/CH-4 ACEA E5-E7
Engine oil consumption	%	<0,1% fuel consumption
Total oil capacity	lt	21,3
Total coolant capacity	lt	18,5

# Alternator

#### \* May vary based on stock availability. However, a primary brand will be used.

Factory		Stamford	
Model		UCI274E	
Prime power prp 3ph+n	KVA	140	
Voltage regulator (voltage accuracy)	+/- %	1	
Poles	N°	4	
Phases	N°	3+N	
Standard windings connection		Star Series	
Stator/rotor impregnation		H (Outdoor Temp 40°C)	
Efficiency	%	91,7	
Engine coupling		Elastic disk	
Short circuit current		>= 300% (3ln)	
Protection degree	IP	23	
Cooling system		Self ventilating	
Maxium overspeed	rpm	2250	
Waveform distortion	%	<5	
Exciter		Diode bridge	

# Standard operating environmental conditions

Ambient temperature	°C	25
Relative humidity	%	30
Max altitude	mt	1000





# **Control Systems on board QPE-C-VSC**





operating scheme - schema di funzionamento

# $\ensuremath{\textbf{QPE}}$ Automatic panel without switching on board

The QPE-C control panel represents the evolution of the panel for the control and managment of the gen set. With its microprocessor logic it is able to meet any user requested features. The dual operation mode manual and automatic guarantees to every type of functionality protection, analysis and control of the generating set in order to make the managment easy and efficient. Variant without transfer switch on board. ATS panel type QC as optional. The panel manages the QC panels directly or any other ATS panel.

### Mechanical features

|--|

### Battery charger

Model		ELCOS - CB1	
Maximum output current	А	2,5	
Output dc voltage (selectable)	Vdc	12-24	
Input ac voltage (selectable)	Vac	220-260	
Frequency	Hz	50-60	

## Data Communication

Data connection port	RS-485
Communication protocol	Mod-bus RTU-8N1

### Remotable functions in terminal box

Gs start Genset contactor close/open command Common alarm - dc output Gs start with key in off position (only in mrs mode) Management of the automatic fuel refilling system Gs lock Mains contactor close/open command Gs test without load Programmable output - volt free output



### Control Module



#### Specifics

Applications Emergency to the mains Stand-alone Construction site/rental Self-production

#### **ENGINE MEASURES**

Fuel tank level % Engine oil pressure bar (1) Engine coolant temperature °c (1) Total run time Partial run time Hours to maintenance Battery voltage Battery charging voltage Start-ups counter Engine speed (2) Engine oil temperature (2) Cooler temperature (2) Engine oil level (2) Engine coolant level (2) Engine coolant pressure (2) Turbo pressure (2) Fuel consumption (2) Tank autonomy - hrs (5) Fuel remaining quatity (5) Fuel used quantity (5)

#### ALTERNATOR MEASURES

Generator voltage 11, 12, 13 Generator voltage 11-n, 12-n, 13-n Generator frequency Generator current 11, 12, 13 Generator apparent power kva Generator active power kwa Generator reactive power kvar Generator accumulated power kwh Power factor cosfi

#### MAINS MEASURES

Mains voltage 11, 12, 13 Mains voltage 11-n, 12-n, 13-n Mains frequency

#### **COMMUNICATION PORTS** Can-bus port

Rs485 port with mod-bus rtu communication Rs232 port for display connection Usb port for parameters saving and firmware update

Brand	ELCOS
Model	MC4
Operating mode	AMF - MRS

Microprocessor logic Back-lit display Programmable from display 16 event log Multiple display languages Stop button Start button Test button Reset alarm button Alarm mute button Fuel transfer pump activation button Glow-plug activation button **PRE-ALARMS/ ALARMS** Common alarm Fuel reserve (pre-alarm) Low fuel level (alarm) Tank overflow Charge alternator failed (dinamo) Low oil pressure (pre-alarm) (1) Low oil pressure (alarm) Oil sensor failed (alarm) High coolant temperature (pre-alarm) (1) High coolant temperature (alarm) Low coolant temperature (pre-alarm) Low water level (1) Water in fuel (1) Battery undervoltage Battery overvoltage Gs failure to start Gs failure to stop Can-bus failure No can-bus communication Genset overload [1, [2, [3 phases Genset short circuit Genset overvoltage Genset undervoltage Genset high frequency Genset low frequency Overspeed Reverse power Earth fault (pre-alarm) Earth fault (alarm) Block from password Can communication failed Maintenance request Emergency button pressed Remote emergency active Forced stop External battery failed Fuel theft Genset negative phase sequence Mains negative phase sequence Fuel theft protection

EQUIPMENT

#### Pre-alarms Alarms Engine measures Alternator measures Mains measures Date and time Operating mode Genset status Mains status Mains contactor status Genset contactor status Digital input and output status Grounding current ma (3) Grounding current threshold ma (3) Delay time of differential protection (3) Glow plugs status CONTROL MODULE FUNCTIONS Automatic start and stop when the mains fails (7)

VISUALIZATIONS ON CONTROL

MODULE/DISPLAY

Remote start and stop when the mains tails ( Remote start and stop Manual start and stop Emergency stop button on panel board Remote emergency stop Remote lock Remote test without load Remote test on load Scheduled start-ups Modbus commands (start, stop, reset, test)

#### CONTROL MODULE SPECIAL FUNCTIONS

(on demand) Automatic charging of an external battery Dummy load (4) Load shedding (4) Redundant starter motor management Fuel monitoring Gs battery load test Idle mode Service phone number indication Variable speed generator Master / slave mode







### **OPTIONAL**

#### Canopy Soundproofing

Canopy customized painting (ral) Double soundproofing -2 dB(A) @ 7 mt Lift-off doors kit Ip 43 conveyors

#### Exhaust

Exhaust pipe Exhaust flexible expansion joint Exhaust flexible pipe (fap) anti-particulate filter Exhaust catalyst (cat)

### Fuel Supply

Oversized tank Fuel connections Bulk tank connections with 3 way valve Automatic fuel refilling system on board Automatic fuel refilling system on trestle

#### CHANNEL Handling

On road trailer Off road trailer

### Engine

Engine pre-heater 230vsuper hot Oil change pump Engine liquids + 50°c, - 40°c (oil and antifreeze) Battery disconnector Automatic refilling oil system 1000 working hours spare parts kit Cyclone air filter Redundant start-up battery kit

### Alternator

Avr pre-arranged for parallel Stator windings thermistors - pt100 - in the alternator box (not managed) Bearing thermistor - pt100 - in the alternator box (not managed) Anti-condensation heater Double bearing Three-phase sensing avr Bi-phase sensing avr

#### Panel & connection

Rcd with adjustable current and excludible Automatic transfer switch (qc) Utf energy meter with arcudi terminal 5 sockets module with magnetothermal circuit breaker and general rcd

#### MC4 optional

Telemonitoring with software Remote panel Rs485/usb converter Rs485/lan converter 16 relais card (volt free output) Gms modem - sms remote management Radiocontrol Gsm remote control system with web application without sim card Gps tracking system

#### PRP

Engines of this rating provide unlimited hours of usage in a variable load application. The average load factor should not exceed 70% of the engine's prime power rating with a maximum number of 500 operational hours at 100% prime power rating. An overload capability of 10% is available, however, is limited to a period of 1 in every 12 hours


LTP

Limited-time running power is defined as the maximum power available, under the agreed operating conditions, for which the generating set is capable of delivering for up to 500h of operation per year with the maintenance intervals. The overload is not allowed.

Data and technical specifications are subject to change in order to update or improve the products.



#### GE.AI.131/120.SS+011





#### GE.AI.131/120.SS+011

