





Image for demonstration purposes

# **Standard equipment**

Generating Set RENTAL BUILDING - diesel

# GE.VO3A.275/250.RB+011

1500 rpm - Threephase - 50Hz - 400V Automatic Panel with AMF without ATS



## Canopy Soundproofing

Removable soundproof canopy Painting canopy (ral) in galvanized sheet steel Soundproofing with class 1 polyester material Handles with key lock and automatic closing Special baffles for air intake and air expulsion Inspection doors with hermetic gasket Automatic doorstop Externally and internally washable with sprayer

Exhaust

Residential exhaust system -35dB(A) Exhaust rain cap

# Fuel Supply

Single wall daily tank with 110% bunded base Plug & play fuel connections Bulk tank connections with 3 way valve Automatic shutdown system for low fuel level Fuel gauge Mechanical fuel gauge Increased fuel hatch for washing

# CHANNEL Handling

Oversized lifting hook Base frame with anti-overturning forklift pockets Loadable side by side for truck transportation Rubber bumpers

## Base Frame

Bunded base at 110% of fuel tank capacity Anti-vibrating mounting pads Battery compartment externally accessible for easy service

## Engine

High coolant temperature and low oil pressure shutdown system Oil pressure and coolant temperature gauge (only with qpe or +14 variant) External oil drain points Oil change pump Engine liquids (oil and antifreeze) Tropicalized radiator Rotating parts protection Electronic speed governor Battery disconnector

# Alternator

Avr automatic voltage regulator Impregnation for marine environment Ip23

# Panel & connection

Emergency stop button Switch on panel board Rcd with adjustable current and excludible Tamperproof panel ip55 Male socket for battery charger and engine pre-heater (if provided) power supply Cable output from rear Ip44 wiring Start-up battery (pre-charged) Plug & play connector for bus communication between controller (only variant +14) 5 sockets module with magnetothermal circuit breaker and general rcd Grounding point Total power terminal box

# Documentation

Ce conformity declaration User and maintenance manual Test report Wirings diagrams Ip 55 document pocket Exploded drawing with spare parts codes









# Normatives

All generating sets are compliant to CE marking 2014/30/UE electromagnetic compatibility 2000/14/CE noise emission for outdoor use Factory-designed systems built according to ISO 9001:2015 CEI EN 60204-1:2018 - Electrical equipment of machines





# **Primary data**

peed	RPM	1500
requency	Hz	50
PRP	KVA	250
Prp - prime power	KW	200,0
.tp - standby power	KVA	275
.tp - standby power	KW	220,0
itandard voltage	V	400/230
Current	Α	361,3
Cosfi	0,8	0,8
General electrical protection		
- ircuit-breaker rated current	А	400
- ÿpe		Switch disconnector on panel board
Circuit-breaker poles	Ν	4P
Optional/notes circuit-breaker		Opening coil
Additional protection		Adjustable and excludable Differential protection
Protection device		Control module
Adjustments tripping set-point (id)	mA	30 - 5000
Adjustments tripping time (t)	sec.	0 - 30
🗭 Noise level +/- 3dB(A)		
WA	dB(A)	91
ound pressure level @ 7 mt	dB(A)	66
ound pressure level @ 1 mt	dB(A)	75
Fuel Consumption		
уре		diesel
itandard fuel tank capacity	lt	400
Autonomy @ 75% load	h	10
uel consumption at 100% load	lt/h	54.4
uel consumption at 75% load	lt/h	44.2
uel consumption at 50% load	lt/h	29.1
🛱 General data		
Rated capacity	Ah	2x120
Auxiliary voltage	V	24
xhaust diameter	mm	100
Weight and Dimensions		
<b>J</b>		
Dimensions (l x w x h)	ст	385x122x205





# Engine

Factory		Volvo
Model		TAD 754 GE
Emissions stage		Stage 3A
Speed governor		Electronic
Radiator	°C	50
Cooling	Tipo	liquid (water + 50% Paraflu11)
Active net power	Kwm	217
Nominal net power	CV	294,8
Cycle	Tipo	4 strokes
Injection	Tipo	Direct
Aspiration	Tipo	Turbo
Numbers of cylinders	Ν	6
Cylinders arrangement		L
Bore	mm	108
Stroke	mm	130
Total displacement	lt	7,142
Engine oil features		15W40-API CI-4/CH-4 ACEA E5-E7
Engine oil consumption	%	<0,1% fuel consumption
Total oil capacity	lt	34
Total coolant capacity	lt	44
lso 8528-5 class		G3

# Alternator

Max altitude

## \* May vary based on stock availability. However, a primary brand will be used.

Factory		Stamford
Model		UCDI274K
Prime power prp 3ph+n	KVA	250
Voltage regulator (voltage accuracy)	+/- %	1
Poles	N°	4
Phases	N°	3+N
Standard windings connection		Star Series
Stator/rotor impregnation		H (Outdoor Temp 40°C)
Efficiency	%	92,7
Engine coupling		Elastic disk
Short circuit current		>= 300% (3ln)
Protection degree	IP	23
Cooling system		Self ventilating
Maxium overspeed	rpm	2250
	%	<5
Exciter		Diode bridge
Standard operating environmental conditions		
Ambient temperature	°C	25
Relative humidity	%	30

mt


1000





# Control Systems on board QPE-C-OSC-250-RB





operating scheme - schema di funzionamento

# **QPE** Control panel

The QPE-C control panel represents the evolution of the panel for the control and managment of the gen set. With its microprocessor logic it is able to meet any user requested features. The dual operation mode manual and automatic guarantees to every type of functionality protection, analysis and control of the generating set in order to make the managment easy and efficient.

# Mechanical features

Protection degree IP 55			
	IP	55	

# Battery charger

Model		ELCOS - CB1
Maximum output current	A	2,5
Output dc voltage (selectable)	Vdc	12-24
Input ac voltage (selectable)	Vac	220-260
Frequency	Hz	50-60

# Sockets module

Protection	Туре	Differential Magnetothermal breakers
Differential sensivity	mA	30 (only for 16A and 32A)
Sockets		N. 1 CE Schuko 16A 230V
Sockets		N. 1 CE 2P+T 16A 230V
Sockets		N. 1 CE 3P+N+T 16A 400V
Sockets		N. 1 CE 3P+N+T 32A 400V
Sockets		N. 1 CE 3P+N+T 63A 400V
Male socket		N. 1 CE 2P+T 16A 230V

# Data Communication

Data connection port	RS-485
Communication protocol	Mod-bus RTU-8N1

# Remotable functions in terminal box

Gs start Genset contactor close/open command Gs lock Mains contactor close/open command



Common alarm - dc output Gs start with key in off position (only in mrs mode) Management of the automatic fuel refilling system

# Control Module



#### Specifics

#### Applications

Emergency to the mains Stand-alone Construction site/rental Self-production

#### **ENGINE MEASURES**

Fuel tank level % Engine oil pressure bar (1) Engine coolant temperature °c (1) Total run time Partial run time Hours to maintenance Battery voltage Battery charging voltage Start-ups counter Engine speed (2) Engine oil temperature (2) Cooler temperature (2) Engine oil level (2) Engine coolant level (2) Engine coolant pressure (2) Turbo pressure (2) Fuel consumption (2) Tank autonomy - hrs (5) Fuel remaining quatity (5) Fuel used quantity (5)

#### ALTERNATOR MEASURES

Generator voltage 11, 12, 13 Generator voltage 11-n, 12-n, 13-n Generator frequency Generator current 11, 12, 13 Generator apparent power kva Generator active power kww Generator reactive power kvar Generator accumulated power kwh Power factor cosfi

#### MAINS MEASURES

Mains voltage 11, 12, 13 Mains voltage 11-n, 12-n, 13-n Mains frequency

### COMMUNICATION PORTS

Can-bus port Rs485 port with mod-bus rtu communication Rs232 port for display connection Usb port for parameters saving and firmware update

EQUIPMENT Microprocessor logic Back-lit display Programmable from display 16 event log Multiple display languages Stop button Start button Test button Reset alarm button Alarm mute button Fuel transfer pump activation button Glow-plug activation button

Gs test without load

Programmable output - volt free output

#### PRE-ALARMS/ ALARMS

Common alarm Fuel reserve (pre-alarm) Low fuel level (alarm) Tank overflow Charge alternator failed (dinamo) Low oil pressure (pre-alarm) (1) Low oil pressure (alarm) Oil sensor failed (alarm) High coolant temperature (pre-alarm) (1) High coolant temperature (alarm) Low coolant temperature (pre-alarm) Low water level (1) Water in fuel (1) Battery undervoltage Battery overvoltage Gs failure to start Gs failure to stop Can-bus failure No can-bus communication Genset overload I1, I2, I3 phases Genset short circuit Genset overvoltage Genset undervoltage Genset high frequency Genset low frequency Overspeed Reverse power Earth fault (pre-alarm) Earth fault (alarm) Block from password Can communication failed Maintenance request Emergency button pressed Remote emergency active Forced stop External battery failed Fuel theft Genset negative phase sequence Mains negative phase sequence Fuel theft protection

# Brand ELCOS Model MC4 Operating mode AMF - MRS

## VISUALIZATIONS ON CONTROL

MODULE/DISPLAY Pre-alarms Alarms Engine measures Alternator measures Mains measures Date and time Operating mode Genset status Mains status Mains contactor status Genset contactor status Digital input and output status Grounding current ma (3) Grounding current threshold ma (3) Delay time of differential protection (3) Glow plugs status

#### **CONTROL MODULE FUNCTIONS**

Automatic start and stop when the mains fails (7) Remote start and stop Remote start and stop Manual start and stop Emergency stop button on panel board Remote emergency stop Remote lock Remote test without load Remote test on load Scheduled start-ups Modbus commands (start, stop, reset, test)

## CONTROL MODULE SPECIAL FUNCTIONS

(on demand) Automatic charging of an external battery Dummy load (4) Load shedding (4) Redundant starter motor management Fuel monitoring Gs battery load test Idle mode Service phone number indication Variable speed generator Master / slave mode

Data and technical specifications are subject to change in order to update or improve the products.





# **OPTIONAL**

## Canopy Soundproofing

Canopy customized painting (ral) Anti-sand louvre High resistence painting for harsh environment condition

Exhaust Spark arrestor

## Fuel Supply

Automatic fuel refilling system on board Fuel refilling from outside with tank overflow lamp

## Handling

On road trailer Off road trailer

# Engine

Engine pre-heater 230v Engine liquids + 50°c, - 40°c (oil and antifreeze) Automatic refilling oil system 1000 working hours spare parts kit Cyclone air filter Redundant start-up battery kit

# Alternator

Avr pre-arranged for parallel Stator windings thermistors - pt100 - in the alternator box (not managed) Bearing thermistor - pt100 - in the alternator box (not managed) Anti-condensation heater Double bearing Three-phase sensing avr Bi-phase sensing avr

## Panel & connection

Automatic transfer switch (qc) Utf energy meter with arcudi terminal Mccb open switch in the event of terminal box panel opening Internal led lighting system into terminal box Internal led lighting system for canopy Siren and generator status lights kit High efficiency start-up battery (pre-charged) Additional sockets for socket module (max 4 sockets) Genset start/stop device on load demand Grounding points Power locks

## MC4 optional

Telemonitoring with software Remote panel Rs485/usb converter Rs485/lan converter 16 relais card (volt free output) Gms modem - sms remote management Radiocontrol Gsm remote control system with web application without sim card Gps tracking system

## PRP

Engines of this rating provide unlimited hours of usage in a variable load application. The average load factor should not exceed 70% of the engine's prime power rating with a maximum number of 500 operational hours at 100% prime power rating. An overload capability of 10% is available, however, is limited to a period of 1 in every 12 hours

LTP

Limited-time running power is defined as the maximum power available, under the agreed operating conditions, for which the generating set is capable of delivering for up to 500h of operation per year with the maintenance intervals. The overload is not allowed.